Remote Guide

WABASH
Your Local Communication Connection

Equipment Controls

TV
Controls TV functions

Power
Turns components On/Off

View Live TV
Switches to live TV view

STB
Used for Set Top Box functions

DVR Controls

Stop
Stops playback of program

30 Sec. Rewind/Fast Forward
Go back or advance by 30 sec.

Rewind/Play/Pause/ Fast Forward/Stop
For use with DVR/VCR/ DVD/VOD Functions

Record
Records selected program

Navigation Controls

Menu
Displays main menu

OK
Press when you want to select a program or highlighted object

Guide
Displays programming guide

Page Back/Forward
Scrolls Side to Side from the current page in the guide

Red/Green/Yellow/ Blue Buttons
Only used for menu functions

Volume +/-
Increases/Decreases volume

Mute
Stops all audio from playing

Number Keys
Used for typing in channels numbers and alphabet letters

Delete
Deletes single character in text entry boxes

Input
Switches between audio video inputs on your TV

Info
Displays information about selected program

Arrows
Allows you to scroll through the guide and menu

Exit
Exits the guide and menu

Page Up/Down
Scrolls Up and Down from the current page in the guide

Channel +/-
Changes channels on the STB

Last
Returns your programming back to the previous channel

Closed Captioning
Enable/Disables Closed Captioning

Turning ON and OFF Television

To turn on TV press TV then POWER
Press STB to control our set top box
To turn off TV press TV then POWER